

SADOWSKY GUITARS LTD.

2107 41ST AVENUE + 4TH FLOOR

LONG ISLAND CITY, NY 11101

TELEPHONE (718) 433-1990

FAX (718) 433-1993

Will Lee Model

Frequency and bandwidth settings are located on the blue switch on the rear control plate. Only one switch position should be **on** at a time.

The positions are as follows:

1 – 500Hz, Q=1 (narrow)

2 - 500Hz, Q=1.7 (wide)

3 – 800Hz, Q=1 (narrow)

4 – 800Hz, Q=1.7 (wide)

The default setting is #2 (Will's choice)

Mini Toggle switch on front of bass:

Towards jack...mid boost bypassed

Towards neck...mid boost engaged

On the control plate there are two trim pots.

Trim pot A adjusts the gain of the mid boost.

Trim pot B controls the total output of the bass when the mid boost is engaged.

We preset the controls as follows:

Set mid boost (A) to maximum (full clockwise). Reduce the output trim (B) until the overall output of the bass is about the same with mid boost engaged and bypassed. This will accentuate the tone difference between the two settings, without affecting your overall output levels.

Take the time to find “your sound” and from there, it is “set it” and “forget it”!

