


FLEX CORE

INSTRUCTIONAL OVERVIEW



* If no midrange control is desired, the midrange boards need not be attached at all. The orange connectors on the EQ are interchangeable.

** If you purchased a Flex Core x:2, you did not receive a Treble board. The Treble function is located on the TOP shaft of the dual pot on the EQ board.

Note: Wire colors may differ from photo.

For complete installation and operating instructions, please visit
www.michaelpopedesign.com/flex_core.

michael
pope
DESIGN