



LAKLAND LH-3 Wiring Diagram

LH-3 Preamp with Volume, Blend, Treble, Mid & Bass Controls and Rear Pickup Coil Selector Switch with internally selectable Mid Frequency Switch.


Two tabs close together, should be jumpered




LAKLAND
LH-3 Midrange Freq. Selections
For more selections visit
www.lakland.com




275 Hz



600 Hz



900 Hz



1100 Hz