

SPL CALCULATIONS

WATTS		SPL	SPL	SPL	SPL	SPL	SPL
	Meters	1.0	2.0	4.0	8.0	16.0	32.0
	Feet	3.3	6.5	13.0	26.0	52.0	104.0

Manufacturer's stated sensitivity							
1	99	93	87	81	75	69	

100	119	113	107	101	95	89	
350	124	118	112	106	100	94	
500	126	120	114	108	102	96	
750	128	122	116	110	104	98	
1000	129	123	117	111	105	99	